




Thank you for using this remote controller. Please use this product on a trial basis immediately after installing the batteries for the first time. if every function works properly, enjoy your use without doing any Settings; otherwise, you have to employ the following method to do some settings, before taking remote control off your TV set. This product has a power cut memory function; so you don't have to redo the settings after replacing the batteries.

Product Introduction

RM-089 is an all-purpose TV remote controller with unique new external design. The product has been designed with intelligent digital brand searching mode and new Point-to-point brand mode and it can be used for controlling most of the TV sets in well-known brands, which satisfy the needs of various consumers. It is the best choice for replacing your damaged and lost TV remote controllers and can facilitate more convenience to your life.

Panel Description



Battery Installation:

Open the battery cover, put in two new AAA(no.7#) alkaline batteries(not attached) According to the"+/-"symbol inside the battery pack as shown in the figure.



Cautions on Battery Use:

- . Do not use old and new batteries or batteries of different model at the same time
- In the event of battery leakage, take out the batteries, wipe the battery Compartment clean: and exchange new batteries.
- If this remote control is intended to be not in use for a long time: please remove The batteries.

Setting of Remote controller


Three methods(method A/B/C) are provided to set this remote control, any one of which can be used in operation.

A. To search mode of point to point

1. Find out the model symbol corresponding to your TV Set model. For example: Haire is "1". Turn on the TV Set and aim the remote controller directly at the TV



Hold "Symbol key"until the indicator is on(about 6 seconds). Don't release the key and the indictor will flash. The remote controller enters symbol searching



------4. Detect whether the keys on the remote control can work normally. If not, repeat from Step Two to reset.

The indicator will go off.



009

SET O

Check list of model symbols

0	1	2	3	4	5	6	7	8
Panasonic	TOSHIBA	PHILIPS	SANYO	SHARP	HITACHI	NEC	SAMSUNG	SONY
9	4	tı	Ø					
LG	DAEWOO	JVC	POLYTRON					

If your TV set belongs to any of the above brands ,you can set by directly using the above setting methods. If not, please set by using the following methods.

B. To search applicable models by entering manual codes

1. Turn on your TV set, and from the code Code List, find a code representing the brand of 009,057,058 The TV. (the code list attached to the back) 2. Press the "SET "key and "POWER" key at the same time until the indicator illuminates. (AIWA) 009

3. Enter a 3-digit code in the first group Corresponding to the model •

4. The indicator goes out.

detect whether the keys on the note control can work normally

if not, restart the setting from Step 1.

Due to too many codes corresponding to your TV model, you are recommended to set your TV set code by code, and finally select One code most suitable for your TV set.

C. Models suitable for automatic searching

1. Turn on the TV set, and aim the remote control at the TV set



2 Hold the"SET"key until the indicator illuminates(about 3 seconds). The indictor will flash. The remote controller enters automatic searching mode. Pay → (SET ★) attention to the TV set.(Don't release "SET" key)

SET O SET 'Key to save and exit. The indicator will go off. 3 When the volume symbol is displayed; release "SET" key to save and exit. The

4 Test whether the keys on the remote control



Restore factory setting

Press the "SET" key and "0" key at the same time, after that release them. The indicating lamp will flash twice means restore is successful.

Warm Tips:

If any problem occurs during setting or using this remote control:

- When you set this remote controller, please carefully follow the procedures of Simple Manual Code Input To Search For Applicable Models. If the remote controller cannot control your TV set after you have set the first group of codes, please set the other codes one by one by following the code sequence. In case all codes cannot make your remote controller work (and when your electric appliance is not included in the list), please try the Fully Auto matic Search For Applicable Models.
 If you have made mistakes during code input, you can simply re-enter a
- If you have made mistakes during code input, you can simply re-enter a proper three-digit code as long as the work indicator does not go out. You need resetting from step I if it goes out.

 When you set by using the Fully Automatic Search For Applicable Models, please be patient during the searching as the codes are too many.

Technical Parameters

Distance of remote control: about 8 meters(depending on types of machine) Battery model: AAA battery, 2 pcs

After-sale Service

If any problem occurs or it fails to work temporally when using this remote control, please contact this company immediately, and we will make every effort to provide you with excellent services. However, this company is not liable for a remote control subjected to unauthorized disassembly or repair.

SKYWORTH-R

OTHER BRAND

B0063216

007.013.024.039.040.043.070.071

082.085.087.098.100.109.110.107.

112.113.138.139.141.142 446.447.013.023.024.039.040.043

Antel

M FOR THE COMPONEN Code

Brand
AIWA
AKIRA
ANHUA
ANIS
AOLINPIKE
AOLINPU
BAIHUA
BAILE
BEIJING
BEKO

CHUNFENG

CHUNLAN

CONROWA

DAEWOO

DALCO

DETRON

DIGITEC

DONGDA

DONGJIE

DONGLIN

ERISSON

ELBA

CIMA

009,057,058 057.096.101.102.104.304.4 017,001,032,047 033.053.055.056.073.078.0 092.108.114.115 033,053,056,079 016,025,033,053,056,079 016,025,012,019,026,027,02 030,031,042 008.011.016.021.023.024.0 043.050.051.053.056.079.09 207.008.012.019.025.027.03 030.031.033.050.053.056.03 091.039.042.051.126.207.34 374.350.170.442.442 155.161 BENO 232 вомва 399.101.421 BPL 013.017.024.033.039.040.04 056 071 073 078 079 086 08 098 107 108 113 114 115 14 145 BUSH 269.291.333 CAIHONG 011,025,016 CAILING 102 CAIXING 023,024,040,043,073 CHANGCHENG 011,016,017,023,024,025,0 043,053,056,001,012,019,03 028,029,030,031,042,079 CHANGFENG 011.053.056.045.046.024.0 CHANGHONG 058.274.100.052.367.368.36 371.372.373.000.008.009.0 014.016.026.028.033.051.0 071.086.087.088.091.092.09 238.189.229.230 CHUANGJIA 397.286.328.073.234

077

073,097,101

057.096.101.102

024.234

	FEIYUE
	FISHER
FOR THE COMPONENTS	FIVE S
Code	FUJITS
	FULI
009,057,058	FUNAI
057.096.101.102.104.304.420.045.	GANGT
017,001,032,047,	GANXII
033.053.055.056.073.078.079.086.	Genera
092.108.114.115	GOLDS
033,053,056,079	GRUND
104	Haier
016,025,033,053,056,079	
016,025,012,019,026,027,028,029,	
030,031,042	HAIHO
008.011.016.021.023.024.026.040.	
043.050.051.053.056.079.091.126.	HAIYAH
207.008.012.019.025.027.028.029.	HISENS
030.031.033.050.053.056.026.079.	11.02.11
091.039.042.051.126.207.343.120.	
374.350.170.442.442	
155.161	
232	
399.101.421	
013.017.024.033.039.040.043.053.	HITACH
056.071.073.078.079.086.087.092.	HIACE
098.107.108.113.114.115.141.142.	нітсні
145	HITCHI
269.291.333	
011,025,016	
102	
023,024,040,043,073	HI-VISI
011,016,017,023,024,025,033,040,	
043,053,056,001,012,019,027,026,	HONG
	1200000000
028,029,030,031,042,079	HUANG
011,053,056,045,046,024,079,033	No constitui soc
058.274.100.052. 367 .368.369.370.	HUANG
371.372.373.000.008.009.010.011.	
014.016.026.028.033.051.057.067.	HUANY
071.086.087.088.091.092.093.168.	-
238.189.229.230	HUAQI
397.286.328.073.234	HUIJIA
016,025,033,053,056,079,124	HUODA
142,107,131	IGO
057.096.101.102	IMPER
291.292.403.293.333.294.295.000.	
006.007.008.010.016.025.033.045.	INTEL
046.048.053.055.056.073.099.167	JIAHUA
448.449.012,042,031	JIALICA
131	
212	JINGXI
201,150,147	JINTA
016,025	
073,097,101	JINXIN

FEMILE	044 046 000 004 005 040 045		
FEIYUE	011,016,023,024,025,040,043		
FISHER	034.060.061.080.153.154.155		
FIVE STAR	057.096.101.102		
FUJITSU	048		
FULI	TOTAL PROPERTY.		
FUNAI	273.047		
GANGTAI	097		
GANXIN	011,017,023,024,027,040,041,043		
General Electric	001.021.022		
GOLDSTAR	009,019,023,024,040,043,098,140		
GRUNDIG	016.025.120.155.161		
Haier	016.025.119.393.394.395.396.397.		
	398.399.400.403.401.402.251.403.		
	103.105.112.118.190.252		
HAIHONG	016,025,026,027,028,029,030,077,		
	103,216,422		
HAIYAN	011,023,024,033,040,043,053,056,079		
HISENSE	115.105.116.404.296.406.407.408.		
	399.270.409.410.411.255.412.413.		
	296.414.000.006.007.008.010.014.		
	015.025.045.046.057.102.103.107.		
	128.129.130.131.138.139.145.148.		
	168.186.187.190.207.215.217.218.		
	219.237.246		
HITACHI	435.436.000.006.007.008.010.014.		
	015.027.048.167		
HITCHI FUFIAN	328.329.330.181.331.332.333.403.		
	334.335.336.337.338.409.339.340.		
	435.436.007.011.015.023.024.028.033.		
	034.040.043.053.056.060.061.065.079		
HI-VISION TV	033.053.055.056.073.078.079.086.		
	092.108.114.115.		
HONGMEL	003,011,016,018,023,024,025,033,		
	040,043,056,009,057,058,079		
HUANGHE	011,016,023,024,025,040,043,051,		
TIOTATOTILE	103,125,178		
HUANGSHAN	011,016,023,024,025,032,033,040,		
AITOOITAIT	043,053,056,079		
HUANYU	011,015,023,024,033,040,043,053,		
TIONNIO			
HUAQIANG	056,009,057,058,079		
WAR DATE OF STREET	033,053,056,079,210		
HUIJIABAN	032 001 017 047		
HUODAKEJI	032,001,017,047		
IGO	004		
IMPERIAL COWN	033,053,056,012,019,025,026,027,		
INTER	028,029,030,031,042,079		
INTEL	200		
JIAHUA	017,047,001,032,033,101,174,196		
JIALICAI	016,025,028,033,053,056,079,124,		
	178		
JINGXINGBAN	104		
JINTA	016,023,024,025,033,040,043,053,		
	056,009,057,058,079		
JINXING	007.011.013.024.025.032.033.039.		
	051 065 071 073 070 001 007 139		

051.065.071.073.079.091.097.138.

162.168.008.397.341.342.296.343.344

345.120.184.362.346.347.140.348.349

JUHUA	011,023,024,033,040,043,053,056
	079
JVC	440.004.089.161
KAIGE	011,016,023,024,025,033,040,043
	053,056,079
KANGHONG	009,058,057
KANGHUA	103
KANGLI	027,012,016,019,025,026,028,030
	031,033,073,120,403,218,246
KANGLI	016,023,024,025,040,043,011,026
	027,028,029,042,005
KANGWEI	077,101,104
KANGYI	016,025,033,053,056,079,121
KONGQUE	011,016,023,024,025,033,040,041
	043,124
KONKA	075.069.179.078.117.351.352.353
	354.355.356.357.358.359.360.361
	296.362.434.011.017.029.032.034
	054.067.071.076.077.079.080.081
	107.113.169.182.198.209.245
KUAILE	016,025,033,053,056,079
KUNLUN	001,011,021,022,033,025,012,042
	040,039
LG	444.445.012.019.031.040.043.
	140
LONGJIANG	011,033,053,056,079
MANTIANXING	114
MECK	057.096.101.102.180.336
MEILE	011,023,024,033,040,043,053,056
	009,057,058,079
MENGMEI	023,024,040,043
MITSUBISHI	011.051
MUDAN	287.114.288.289.290.001.002.011
	016.020.021.022.025.032.033.040
	043.053.056.059.063.065.079.174
	205.233.234
NANBAO	016,025,033,053,056,009,057,058
A. H.	079
NEC	004.006.011.016.024.025.033.053
	056.079.089.140
NIKON	009,057,058
NOBEL	397.291.299
OND	004
ORION	006.013.024.039.040.041.043.070
OKION	
	071.082.085.087.098.100.107.109 110.112.113.138.127.139.141.142
OPVICA	153.154.155
ORVICA	290.096.
OULIN	101
PANASONIC (NATIONAL)	428. 429 .430.001.002.014.015.020
21121	021.022.059.066.156.233
PANDA	033.051.062.310.241.403.311.340
	341.312.296.397.313.314.181.292
	153.001.011.016.021.022.023.024

025 026 028 040 043 053 056 009

057.058.073.079.089.091.061.124.

125.197.234.241.263.233

PHILCO
PHILIPS
PILOT
PIONNER
POLYTRON
PRIMA(XIAHUA)
THE SECTION OF THE PARTY OF THE
QINGDAO
RCA
RIHONG
CATE OF STREET
RISHENG
RIZHI
ROLSEN
ROWA
DUDIN
RUBIN
RUYI
SAIGE
SALORA
SAMSUNG
100000000000000000000000000000000000000
SANJIAN
SANKEN
SANLING
SANYO
SANYUAN
SEG
SEYE
SVA
SHANGHAI
SHANSHUI
SHAOFENG
SHARP
SHENCAI
SHENGCAI
SHENGLI
SHENYANG
Committee and a second of the
SHERWOOD
SHUYUAN
SILVER

	007
R	000.001.010.014.021.022.089.090.
	091.128.129.130.034.060.061.080
ON	151,175,201,302.415.358.403.416.
	417.418.419
(IAHUA)	055.242.080.310.273.051.316.317.
	318.319.32 <mark>0.0</mark> 84. 357 .321.126.198.
	322.323.324.325.326.327.011.016.
	024.027.025.033.053.054.056.060.
	073.079.095.098.199.206.214.261.
	262.266
.0	001,011,021,022,033,053,056,079
	151
	073
G	097
	073,097
	000.010.014.089.090.091.128.129.
	130
-	296.297.413.298.397.422.299.084.
	011.016.023.024.025.040.043.096.
	127.150.162.216.236
	023
	011,015,023,024,040,043,
	011,025,016
	008.034.060.061.080.105.153.054.
	155
NG	441.442.443.008.011.016.021.024.
	025.033.037.039.040.043.050.051.
	091.113.123.235
1	033,053,056,079
1	215
3	036,044
	437.000.007.008.014.015.033.035.
	053.056.079.105.132.133.134.163.205
N.	003,011,016,018,023,024,025,040,043
	034.060.061.080
	097
	183,184.180,397.299
HAI	009,011,016,017,022,023,024,025,
	033,040,043,053,056,057,058,079,
	123
łUI	008
NG	011,015,000,006,007,023
	431.432.003.016.018.025.135.136.137
AI .	007,016,025,033,053,056,079
CAI	057,101
1	004
NG	011,016,025,046,045,033
DOD	016,025
AN	131,403
-	033.053.056.073.078.079.086.092.
	108.114.115

141.162.171	
007	
000.001.010.014.021.022.089.090.	
091.128.129.130.034.060.061.080	
	CONCDIAN
151,175,201,302.415.358.403.416.	SONGDIAN
417.418.419	SUNY
055.242.080.310.273.051.316.317.	CUMO
318.319.320.084.357.321.126.198.	SUMO
322.323. 324 .325.326.327.011.016.	SUPRA
024.027.025.033.053.054.056.060.	T41011411
073.079.095.098.199.206.214.261.	TAISHAN
262.266	
001,011,021,022,033,053,056,079	TCL
151	
073	-
097	TIANE
073,097	TIANGENGBAN
000.010.014.089.090.091.128.129.	TIANKEBAN
130	THOMOSON
296.297.413.298.397.422. <mark>299</mark> .084.	тово
011.016.023.024.025.040.043.096.	TONGGUANG
127.150.162.216.236	TOSHIBA
023	
011,015,023,024,040,043,	
011,025,016	VIDEOCON
008.034.060.061.080.105.153.054.	_
155	WARUMAIA
441. 442 .443.008.011.016.021.024.	WEIPAI
025.033.037.039.040.043.050.051.	XIHU
091.113.123.235	
033,053,056,079	
215	
036,044	XINAGHAI
437 .000.007.008.014.015.033.035.	XINGMENBAN
053.056.079.105.132.133.134.163.205	XUELIAN
003,011,016,018,023,024,025,040,043	YAJIA
034.060.061.080	YINGGE
097	YONGGU
183,184.180,397.299	YOULANASI
009,011,016,017,022,023,024,025,	YOUSIDA
033,040,043,053,056,057,058,079,	888
123	230CH
008	255/500/1000
011,015,000,006,007,023	CHINESE TV
431.432.003.016.018.025.135.136.137	

0.0	0.45 400 400 0.40 000 074 075 07
GB	045.188.108.046.222.374.375.376
	377.378.379.380.381.382.383.384
	385.386.387.388.389.390.391.392
	011.025.033.060.070.071.072.073
	074.079.083.101.107. 109 .172.18
	185.192.193.194.208.220. 221 .224
	225.226.227.228.234.239.240.25
	258.259. 281.222
_	101
	049.427.005.041.094.106.153.154
_	158.173.243
	201
	033.053.055.056.073.078.079.086
_	092.108.114.115.100.327.140.045
	011,016,025,042,038,031,030,029
	028,027
_	051.068.071.073.082.084.085.110
	151.212.213.244.053.111.083.363
	364.365.366.084
	003,011,018
<u></u>	101
	101
	450.451.034.060.061.074.080.160.205
	016,025,033,053,056,077,079,101,103
_	033,053,056,079
	433,434,000,007,008,014,015,016
	027.028.030.033.053.056.079.089
	090.091.160
7/	033.053.055.056.073.078.079.086
	092.108.114.115.091
_	031,012,042
	016.025
_	165.204.203.300.301.302.303.399
	304.403.305.306.307.308.266.309
	011.023.024.033.038.040.043.053
	079.098.165.202.203.204
_	016,025,033,053,056,079
	104

023,024,040,043,009,057,058

273.276.278.271.272.420.421.399.

422.291.054.268.423.409.095.424.

425.269.103.104.216.234.270.271.

272 273 274 275 276 277 278 279

280 281 282 009 058 099 084 075

097 131 119 036 044 114 144 146

149.147.234.164.166.168.231.249.250

251.252.253.254.255.256.270.271.272

036,044,057,073,077,097,101,102

103,104,106,114,304,231

016,023,024,025,040,043

016,023,024,025,040,043

011,023,024,040,043

016,025,009,057,058

033,053,056,079

159

157

033,053,056,079