

Antel®

Operating instruction

Universal Satellite receiver Remote

■ RM-3335+


Prelude

Thank you for using our products! It is our honour to serve you. Read the instructions carefully before using our products for convenience.

About This Remote controller

RM-3335+ multi-function remote controller is the latest product for SAT. It can control almost all SAT made in China or abroad. It has functions of manual and auto-searching. With its beautiful body shape and warning indicator, it is easy and convenient for you to handle.

Panel Description



Installing the batteries

Open the battery lid and pay attention to the +/- marks. Insert two new AAA (size 7) batteries (not supplied).



Note on batteries

- ◆ Do not mix old batteries with new ones or mix different types of batteries together.
- ◆ If the electrolyte leaks inside the battery compartment, clean it with a piece of cloth and replace the old batteries with new ones.

- ◆ To prevent the electrolyte from leaking, remove the batteries when you plan not to use the controller for a long period of time.
- ◆ Replaced with new batteries, previous setup will be saved. This remote control can keep memory for 24 hours after power off.

Setting

In the first time when you use the remote, it is in factory status and can directly remote 10 more models. So you can setup it as follows.
(Notice: press "SET" and "9" simultaneously then release, the remote go into factory status)

A. Input Code

1. Please turn on SAT and make the remote face it;



2. Press "SET" and "POWER" simultaneously and do not release them until the indicator is on;



3. After that, please input the 2-digit code.

B. Auto Search

1. Press "SET" and "POWER" simultaneously and do not release them until the indicator is on;



2. Press "CHA" one time and point the remote to the receiver. The indicator will flash every 2 seconds;




3. Notices when the channel is changed, press "SET" at once.



MODEL	C/N	CODE
06-0225	HSR309	05
16A-SANSUNG	HSR392	04, 29, 31
19A-ASTRA-SAT	HSR363	04, 29, 31
20A-SANSUNG	HSR364	34
21A-SR-X1400D	HSR365	52
3A-STAR TRACK 550D	HSR359	37
3B-STAR SAT SR-X2200R	HSR367	44
880 SERIES	HSR076	09
SR11-SERIES	HSR219	32
ACC	HSR257	06, 42
ACC114	HSR226	32
ACC131	HSR226	32
ALFA GOLD	HSR114	52

MODEL	C/N	CODE	MODEL	C/N	CODE
Aife Gold Digital	HSR124	52	LY7000D-X3	HSR330	52
AM-1500Z	HSR243	37	LURANCE	HSR275	22, 35
ARISAT	HSR324	50	MAGNUM NH 9500	HSR201	23, 36, 49
ASTRASAT	HSR344	31	MATRIX	HSR330	38
ASTROVOX 2000	HSR270	44	MATRIX	HSR329	52
BEAUSAT	HSR391	07, 14	MATRIX STARLINK	HSR230	34
BEAUSAT	HSR392	52	MEAXI 0404	HSR392	52
BEAUSAT	HSR310	16, 17, 18	MEDIACOM(RC-1405)	HSR268	04, 21, 27, 34, 45
BEAUSAT 2C1	HSR292	22, 35	MICRO-X	HSR236	38
BEAUSAT 900 SERIES	HSR018	23, 36, 49	NEOSAT	HSR047	35
BEAUSAT-2000-2007	HSR174	07	NEW9000	HSR166	33
BETEEL RIR7	HSR342	04, 16, 17, 18, 19	NEWMAX	HSR262	13
BRADWIN	HSR213	16, 17, 18	NEWMAX550	HSR295	34
BR3A-08	HSR132	16, 17, 18	NEWMAX5500	HSR393	34
BK3B-C17	HSR312	12	NHE	HSR148	06, 42
BK3B-C4	HSR163	12	NHE	HSR202	06, 42
BK7A-C3	HSR341	12	OM-R100 ALPHA	HSR162	04, 21, 27, 34, 45
CHATEAU 156	HSR189	12	OPEN SKY	HSR232	05
D-1100 XCI	HSR066	40	PENTAL	HSR044	02
DS2APICI	HSR326	02	OPENAL	HSR034	02
DANASAT G-5	HSR025	23, 36, 49	OPENAL NEW	HSR134	02
DANSAT	HSR159	04, 21, 27, 34, 45	ORIBICLE	HSR190	44
DANSAT	HSR391	06	PAMSAT	HSR190	33
DANSAT G-3	HSR022	23, 36, 49	PANASAT	HSR177	40
DANSAT G-4 G7	HSR024	23, 36, 49	PATRIOT	HSR034	04, 21, 27, 34, 45
DANSAT G-5	HSR020	23, 36, 49	PATRIOT II	HSR203	04, 21, 27, 34, 45
DANSAT G4.5 G.7.8.9	HSR326	23, 36, 49	PATRIOT II	HSR204	04, 21, 27, 34, 45
DG19 HYUNDAI	HSR282	37	PENTAX	HSR140	13
DP21 AAA	HSR261	07	POWRT SKY	HSR039	30
DUALVIEW	HSR010	24, 26, 28	PREMIUM	HSR228	07, 47
DIGITAL TELECOM	HSR033	44	PREMIUM	HSR263	07, 47
DK SAT	HSR030	32	PRIMA	HSR255	06
DSR-97000	HSR119	33	PRIMA	HSR245	50
DX-564A	HSR117	37	RC03H	HSR262	04, 21, 27, 34, 45
DYNASAT	HSR041	32	RC06A	HSR115	04, 21, 27, 34, 45
ECHOSTAR	HSR026	24, 26, 28	RC102	HSR125	04, 21, 27, 34, 45
ECHOSTAR	HSR075	04, 21, 27, 34, 45	RC18(MW)	HSR006	07
ECHOSTAR	HSR289	16, 42, 43	RC2402	HSR160	04, 21, 27, 34, 45
ECHOSTAR	HSR304	16, 17, 18	RC2402	HSR192	04, 21, 27, 34, 45
ECHOSTAR	HSR147	19	RC30H	HSR177	04, 21, 27, 34, 45
EZ EEE SAT	HSR200	33	RC6509	HSR036	22, 35
EM-TEC	HSR163	16	RC6509-0100	HSR037	33
EURO-BOX	HSR111	41	RECEIVER	HSR161	28
EURO-BOX	HSR328	04, 42, 43	ROTANA	HSR337	37
EURO-BOX	HSR299	41	RS-101P	HSR164	24, 26, 53
FORTEC STAR	HSR107	31	RS-101P	HSR404	24, 26, 53
FORTEC STAR	HSR157	00	RS-201P	HSR207	24, 26, 53
FORTEC STAR5100PLUS	HSR131	00	RS-210P	HSR106	24, 26, 53
FORTEC STAR61	HSR338	07	RS-271	HSR110	24, 26, 53
FUJISAT	HSR324	37	RT04	HSR042	33
GALAXY 2000D	HSR196	01, 47	SAMART	HSR012	38
G-BOX Sat1	HSR183	07	SAMSAT	HSR040	02
G-BOX Sat1	HSR238	07	SAMSUNG	HSR151	22, 35
GIZZEN S230	HSR158	23, 36, 49	SARSITO	HSR170	22, 35
GOLD	HSR114	32	SARYSAT/MEDIA16	HSR111	12
GOLDSTAR	HSR158	07	SAT-HSR372	HSR372	34
GREY CASE	HSR028	38	SHOWNIC	HSR180	16, 17, 18
SAT-HSR372	HSR372	34	SIGNAL	HSR131	07
HSR397	HSR397	33	SIGNAL	HSR024	07
HUMAX RS-101P(UHF)	HSR042	24, 26, 53	SIGNAL444	HSR269	47
HYUNDAI	HSR133	33	SAT VIEW	HSR038	16, 17, 18
KALLEY	HSR015	52	SKY-1	HSR103	37
KYOTO	HSR179	01, 47	SMART	HSR298	33
LAWRENCE LT 7000D	HSR179	22, 35	SONY/SAT ACC	HSR217	06, 42
LT7000D-X3	HSR160	52	SR-1500D	HSR124	04, 21, 27, 34, 45
			SR-444	HSR327	07

www.antel.com



Specifications

Operable distance: More than 8 meters.
 Power requirement: Two size AAA batteries.
 Dimensions: 53X173X23mm(w/h/d)
 Mass: approx. 100g(not including batteries)

Service

If you have troubles in using the controller please contact us. We will do our best to service you. Please don't open the controller by yourself. We will not take the responsibility if you open it by yourself.